

48 (Subject to change)

Oil treatment

Protective treatment





	Description
Definition / objective	Applying the floor oil to the floor coverings using the application tool with a cover. Suitable for porous, absorbent non-textile floor coverings.
Preparatory work	Select suitable products to match the surface to be protected (type / square metres).
	Put up the warning sign.
	Check for oil treatment suitability. Pre-test the absorbency of the floor covering.
	If required: Remove fine to medium scratches in the floor covering. Dry sanding
	If necessary: Remove the adhering dirt (single-stage scrubbing or single-stage wet scrubbing and wet vacuuming).
	After wet cleaning: Leave the floor covering to dry completely.
	Remove any loose dirt (dust-binding mopping or dry vacuum cleaning).
Main task	Pour a little bit of undiluted wood oil onto the dry, clean floor covering and apply with the applicati tool and apply it evenly, moving in slightly overlapping passes in circular movements and leave to soak.
	If necessary: After 10 minutes, oil the oiled section again, pour a little wood oil on the freshly oiled section and spread as described in step 1 of the main work. Repeat this step until the covering is saturated with oil.
	After 10 minutes, remove excess oil completely with the painting tool and clean coating. No oil should remain on the surface and dry up.
	Perform a visual check.
	For the next section, pour a little wood oil on the edge of the oiled surface and spread as describe above. Repeat steps 1 to 3 of the main work until the whole surface is oiled. Work in sections and backwards towards the exit.
	Leave the floor covering to dry for 3 days.
	Fine sanding: Work the oiled surface with the HS single-disc machine and the blue scouring pad in overlapping paths and circular movements, trim the wood fibres that are sticking up.
	Turn or replace the dirty pad in good time, then continue working with the single-disc machine unt the entire surface has been worked.
	Perform a visual check.
Final steps	Remove the warning sign once the floor covering is dry.
	Wash out the used covers an pads and dispose of them in a fire-safe container.
	Check the cable, clean it and roll it up loosely.
	Dispose of any waste. Clean the cleaning equipment and replace as needed.
After treatment	Allow the floor covering to dry for a further 4 days. Allow the oil to cure completely.
	Remove any loose dirt (dust-binding mopping or dry vacuum cleaning).
Comments	 Wear the personal protective equipment (PPE) required by company regulations, safety data sheets and / or instructions for use. Always check in advance which product meets your requirements (see Wetrok Cleaning & Care Instructions). Wetrok AG accepts no liability for damage caused by improper use or incorrect product selection.

(Subject to change) 49