



# PRODUCT DATASHEET

Kitchen cleaning - Crockery by hand


## Wetrok Gastronet

Crockery detergent for manual use





# Wetrok Gastronet



**pH value (Concentrate):** 7–8

**Important ingredients:**

Surfactants, Skin care additive, Fragrances, Colourant, Preservatives

**Recommended dosage:**



**Crockery maintenance cleaning**

0.01–0.02 l/10 l



**Surface maintenance cleaning**

0.1–0.2 l/10 l

METHODS  
finder



**APPLICATION**

- Crockery and surface cleaner
- For manual cleaning of crockery and kitchen appliances
- For cleaning in food processing areas (canteens, restaurants, industrial and manufacturing plants)

**PROPERTIES**

- High-lather
- pH-neutral
- Lightly scented
- Skin and material-friendly

**PLEASE NOTE**

- Not suitable for machine dish washing (lathering)

**RECOMMENDED APPLICATION METHOD**

**Wet wiping (by hand, crockery)**

Place dirty crockery in the cleaning solution. Clean your crockery with a white hand pad or brush (wet scrubbing). Finally, rinse thoroughly with water and dry.

**STORAGE**

Store in original container at 15 to 25°C and protected from sunlight. Keep container closed when not in use.

*Durability (unopened): 24 Month*

Wetrok AG shall have no liability whatsoever for damage caused by incorrect use. Observe special cleaning and care instructions from the floor covering manufacturer.