


Brush vacuum cleaning



42005 Micro-fleece bag
Karpawel



40711 Karpawel 36 Plus






41610 Picojet M



40711 Monovac Comfort 6



Description

Definition / objective	<p>Removing dry, loose dirt from floor coverings using the brush vacuum cleaner. Suitable for low-pile, robust textile floor coverings, carpets and upholstery. The motor-driven brush roller will achieve a better cleaning result than dry vacuum cleaning.</p>
Preparatory work	<p>Select suitable products to match the surface to be cleaned (type / square metres) and the type of soiling.</p> <p>Check, equip and ready the vacuum cleaner and all accessories in compliance with the instructions for use.</p> <p> Put up the warning sign.</p> <p>Pick up and dispose of very coarse dirt (e.g. strings, wadded-up paper, etc.) by hand. Remove chewing gum, if any.</p> <p>Switch on the vacuum cleaner and adjust the brush roller on the suction nozzle to the correct height.</p>
Main task	<p> Use the brush vacuum cleaner to brush-vacuum the area in slightly overlapping passes; start from the wall socket and work your way across the room.</p> <p> Perform a visual check.</p>
Final steps	<p>Check the power cable for visible damage, clean the cable and roll it up loosely towards the plug.</p> <p>Remove the warning sign.</p> <p>Check the brush roller and remove any entangled hairs, threads, etc.</p> <p>Check the fill level of the filter bag; change the bag if it is full.</p> <p>Dispose of any waste.</p> <p>Clean the cleaning equipment and replace as needed.</p>
Comments	<ul style="list-style-type: none"> - Wear the personal protective equipment (PPE) required by company regulations, safety data sheets and / or instructions for use. - Always check in advance which product meets your requirements (see Wetrok Cleaning & Care Instructions). - Wetrok AG accepts no liability for damage caused by improper use or incorrect product selection.