



PRODUCT DATASHEET

Kitchen cleaning - Crockery by hand


Wetrok Gastronet

Crockery detergent for manual use





Wetrok Gastronet



pH value (Concentrate): 7–8

Important ingredients:

Surfactants, Skin care additive, Fragrances, Colourant, Preservatives

Recommended dosage:



Crockery maintenance cleaning

0.01–0.02 l/10 l



Surface maintenance cleaning

0.1–0.2 l/10 l

METHODS
finder



APPLICATION

- Crockery and surface cleaner
- For manual cleaning of crockery and kitchen appliances
- For cleaning in food processing areas (canteens, restaurants, industrial and manufacturing plants)

PROPERTIES

- High-lather
- pH-neutral
- Lightly scented
- Skin and material-friendly

PLEASE NOTE

- Not suitable for machine dish washing (lathering)

RECOMMENDED APPLICATION METHOD

Wet wiping (by hand, crockery)

Place dirty crockery in the cleaning solution. Clean your crockery with a white hand pad or brush (wet scrubbing). Finally, rinse thoroughly with water and dry.

STORAGE

Store in original container at 15 to 25°C and protected from sunlight. Keep container closed when not in use.

Durability (unopened): 24 Month

Wetrok AG shall have no liability whatsoever for damage caused by incorrect use. Observe special cleaning and care instructions from the floor covering manufacturer.