



PRODUCT DATASHEET

Disinfection - Wipe-down surface disinfection

Wetrok SintOx 3%

Ready-to-use disinfectant, ideal for the food industry - no need to rinse off





Wetrok SintOx 3%



pH value (Concentrate): 2.5–3.5

Important ingredients:

Hydrogen peroxide 1.5 g/100 g

APPLICATION

- Ready-to-use surface disinfectant based on hydrogen peroxide/silver compounds
- Applications:
Healthcare, veterinary medicine, food industry and feedstuffs sector

PROPERTIES

- Bactericidal (standard bacteria)
- Yeasticidal (*C. albicans*)
- Effective against enveloped viruses (influenza)
- Non-foaming
- Does not need to be rinsed off

GOOD TO KNOW

- Fully effective against bacteria, yeast fungi and enveloped viruses after 15 min. contact time.
- Non-hazardous, no environmentally harmful degradation products are formed

PLEASE NOTE

- Brass may discolour
- Self-shining dispersions may be affected by regular application
- When using on paintwork or facing materials, it is advisable to test the product in a concealed spot before use

RECOMMENDED APPLICATION METHOD

Surface disinfection

Disinfect the cleaned, dry surface using a pre-wetted or lightly wrung-out mop, applying light pressure. Apply a sufficient amount of disinfectant. The entire surface must be wetted. Observe the contact time. Wear gloves!

DOSAGE AND APPLICATION TIME

Effectiveness	Testing methods	Dosage (%)	Contact time
Bactericidal, yeasticidal	EN 16615	100	15 min
Bactericidal	EN 13697	100	15 min
Fungicidal	EN 1650, clean conditions	100	30 min
Influenza A (H1N1)	EN 14476	100	30 s
Influenza A (H3N8)	EN 14476	100	30 s

STORAGE

Store in original container at 15 to 25°C and protected from sunlight. Keep container closed when not in use. Protect against frost.

Please refer to the product labels for information about the shelf life before opening.

Wetrok AG shall have no liability whatsoever for damage caused by incorrect use. Observe special cleaning and care instructions from the floor covering manufacturer.

METHODS
finder

